

Model: WS Concrete Box 217x162

Family: WALL-SMART

DWG NO. 10-04-162-SPC

PRODUCT SPEC.

REVISION A

DATE 29/Apr./2014



Make Your Wall Smart

Wall-Smart concrete/block installation box:

• Wall should be plastered up to the front frame segments (item #1).

Model No.: 10-01-162

- Front frame segments (item #1) should be removed after the wall was plastered (to be replaced with the adapter).
- For low voltage use only.
- Before installation, read Wall-smart installation instruction No. 10-01-00103-INS

