

Model: WS RETROFIT FOR BLACK NOVA

084-1-929

1MODULE LOW V

Family:

WALL-SMART 084-4-929

DWG NO.

PRODUCT SPEC.

REVISION

DATE 08/DEC/2022




Make Your Wall Smart

"WS RETROFIT FOR BLACK NOVA 1MODULE LOW V" - Product description:


The "WS RETROFIT FOR BLACK NOVA 1MODULE LOW V" is an adapter for in-wall nearly flush retrofit installation of 1 module low voltage Black Nova keypads.

The "WS RETROFIT FOR BLACK NOVA 1MODULE LOW V" firmly mounts the keypad while allowing easy insertion, removal and operation.




Key features and benefits:


- Nearly flush with the wall (3mm [0.12"] on-wall thickness).
- Allows easy insertion and removal of the keypad.
- Wall mount contains depth calibration mechanism.
- Designed to be installed in board thickness ranging from ½" up to 1".
- Designed for the use with 2 column square Lutron keypads (keypad is not included).
- Adapter kit contains:
 - 1. (X2) Wall mount base;
 - 2. (X1) Installation platform;
 - 3. (X1) Keypad adapter plate;
 - 4. (X1) Template;
 - 5. (X1) Adhesive curing retention plate;
 - 6. (X4) M3 nuts;
 - 7. (X4) M3x12 flush head screws;
- Structural adhesive is not included in the wall mount kit.



Key properties:

- Dimensions: (W/H/D): 121.8mm (4.8")/ 121.8mm (4.8")/ 41.8mm (1.65")
- Weight: 0.1Kg, 0.22lbs.
- Material: Moisture resistant MDF





by Wall-Smart Ltd.

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS INFORMATION CONTAINED HEREIN IS PROPRIETARY AND MAY NOT BE USED, REPRODUCED OR COPIED WITHOUT WRITTEN CONSENT OF WALL-SMART •



WS RETROFIT FOR BLACK NOVA Model:

084-1-929

1MODULE LOW V

Family: **WALL-SMART**

DWG NO. 084-4-929

PRODUCT SPEC.

REVISION


DATE 08/DEC/2022





2. ROUTE NECESSARY CABLES

3. CLEAN THE INNER SIDE OF THE BOARD WITH A DAMP CLOTH



4. INSERT AND ATTACH TO THE BACK OF THE BOARD 2 BASE UNITS APPLY STRUCTURAL ADHESIVE (MS POLYMER) (ADHESIVE IS NOT PART OF THE KIT)

INSTALLATION PLATFORM





ADHESIVE CURING RETENTION PLATE


INSERT AND ROTATE TO POSITION:




- 6. INSERT THE ADHESIVE CURING RETENTION PLATE.
- 7. LIGHTLY TIGHTEN THE PLATFORM SCREWS.
- 8. LET THE ADHESIVE CURE ACCORDING THE ADHESIVE MANUFACTURER INSTRUCTION.









9. UNSCREW THE PLATRORM FEW SCREW TURNS TO RELEASE THE RETENTION PLATE AND REMOVE THE RETENTION PLATE.

- 10. ADJUST THE DEPTH OF THE PLATFORM.
- 11. ATTACH THE KEYPAD ADAPTER PLATE TO THE KAYPAD.
- 12. CLICK IN THE KEYPAD.



Model: WS RETROFIT FOR BLACK NOVA 1MODULE LOW V

Family: **WALL-SMART**

DWG NO. 084-4-929

084-1-929 Model No.:

PRODUCT SPEC.

REVISION

DATE 08/DEC/2022



CUTTING TEMPLATE:

